



NOTE: INSTALL FLASHING TAPE OVER BRACKET ONTO BUILDING UNDERLAY AS PER E2/AS1 fig 68, ALSO REFER TO DETAIL 510

MANUFACTURED GALVANIZED STEEL 'H' OR 'U' BRACKET FOR PARALLEL JOISTS OR USE 'L' BRACKET FOR RIGHT ANGLE CONNECTIONS

INSTALL DECK JOIST AFTER CLADDING IS FINISH PLASTERED
40mm GAP RECOMMENDED FOR FIXINGS AND PLASTERING

SCALE 1:5

STO POREN SYSTEM	STO POREN PANEL CLADDING SYSTEM	PP 512
	PARALLEL DECK JOIST BRACKET	2014

The information contained in this detail is based on our experience and testing and represents the latest information available at the date of issue. This detail is intended for use by the design professional and users of Sto products to assist in developing specific project details to be used in conjunction with a Sto Specification. We reserve the right to alter or update information at any time without prior notice & it is the responsibility of the specifier and/or the project manager to insure that they have the current Sto details and specifications.