



NOTE:

LEAVE 40mm DRAINAGE GAP IN SEALANT AT BOTTOM OF FAN COVER.
 INSTALL FLASHING TAPE 100mm AROUND PIPE ONTO WALL UNDERLAY AND WRAP 25mm ROUND PIPE OR USE PROPRIETARY SEAL.
 FOR FLEXIBLE PIPES, TAPE PIPE TO FAN COVER, APPLY STO JOINT SEAL TAPE AROUND FAN BEFORE PLACING IN HOLE. ALWAYS FINISH RENDER BEFORE INSTALLING FAN COVER

SCALE 1:2

STO BRICK SYSTEM	STO BRICK SYSTEM	PB 356
	FAN VENT DETAIL	2019