



STOARMAT PLASTER SYSTEM

1. PROVIDE 6mm MIN.FILLET BEAD OF MS SEALANT TO JAMBS & SILL
2. BUILDER TO INSTALL FLASHING TAPE TO CORNERS & SILL OVER WALL UNDERLAY
3. POSITION WINDOW OFF BOARD BY 2-3mm TO ALLOW FOR STOARMAT JAMB & SILL FLASHINGS

WARNING: SOME BRANDS OF ALUMINIUM JOINERY HAVE DRAINAGE VENTS IN THE BOTTOM EDGE OF THE SILL FLANGE. ENSURE DRAINAGE VENTS REMAIN CLEAR.

SCALE 1:2

STO/ VENTCLAD	STOARMAT CONSTRUCTION SYSTEM	VFCS 401
	ALUMINIUM JOINERY - SILL DETAIL	2014

The information contained in this detail is based on our experience and testing and represents the latest information available at the date of issue. This detail is intended for use by the design professional and users of Sto products to assist in developing specific project details to be used in conjunction with a Sto Specification. We reserve the right to alter or update information at any time without prior notice & it is the responsibility of the specifier and/or the project manager to insure that they have the current Sto details and specifications.